

# GPAttitudeSequence

De Wiki

Aller à : [navigation](#), [rechercher](#)  
[GPAttitudeSequence](#)

## Sommaire

- [1 How to call it](#)
- [2 Display](#)
  - [2.1 Reference date](#)
  - [2.2 List of attitude laws](#)
  - [2.3 Sequence](#)
- [3 How to use it](#)
- [4 How it is stored](#)

## How to call it

For using the [GPAttitudeSequence](#) class the developer has only to create such an object with these two possibilities:

- With just two **boolean** to tell if the switches and the law list will be displayed one below the other (**false**) one or just one by one (**true**)

```
attSeq = new GPAttitudeSequence(false, true);
```

- Or with an additional parameter that corresponds to an absolute date which will be used as a reference date (for relative positioning of attitude laws).

```
AbsoluteDate date0 =
    new AbsoluteDate(2010, 1, 1, TimeScalesFactory.getUTC());
attSeq = new GPAttitudeSequence(date0, false, false);
```

## Display

### Reference date

First, the user will have to select a reference date. There are two possibilities:

- “**custom**”: a specific date will be entered by the user
- “**external**”: in that case no modification of the date is available as it corresponds to the date initially defined (note that this date may be automatically updated if the initial orbit date is modified).

Reference Date:

Date mode:  custom  external

External date:  UTC

## List of attitude laws

Then, a button appears that allows displaying a new window to define a set of available attitude laws. Each law is defined as below:

- Name of the law
- Type of the law (local orbital frame (**LOF**), inertial, sun pointing ...)
- Law evolution (constant or spinned)
- Then data linked to the type of law. As an example for **LOF** attitude law, the user will have to select which **LOF** to take into account and eventually angle bias.

**Attitude Laws List**

Amount of laws \*

Number of the law    [Items +/-](#)

**Law1**

Attitude Law: \*

Law name: \*

Law type:

Law evolution:

LOF Att. Law: \*

Local Orbital Frame:

Display expert config

Angles bias \*

Rotation: \*

Deactivate conversions

Order: \*

Psi:

Theta: \*

Phi:

## Sequence

At last, the user will get a choice between:

- A simple attitude sequence with only a single law chosen in the previous list (available since V1.3)

version)

**Attitude Laws:**

Mode: \*  Switch  Simple

Simple Law: \*

- A more sophisticated definition of the attitude sequence using the PATRIUS "event switch" possibility. The user will have to define one or several switches defined by the following data:
  - The attitude law before the event (taken in the previous list)
  - The attitude law once the event occurred (taken in the previous list)
  - The type of event and data related to it.

This "event switch" is a very powerful option that allows defining relatively shortly a whole mission. For example, if we want to define the fact that the vehicle is LVLH oriented in eclipse and Sun pointing out of eclipse, we will only have to define two switches calling to two attitude laws:

- Switch #1 with entering in eclipse as orbital event and law before "Sun pointing" and law after "LVLH"
- Switch #2 with exiting in eclipse as orbital event and law before "LVLH" and law after "Sun pointing"

**Attitude Laws:**

**Switches:**

Amount of switches

Number of the switch    [Items +/-](#)

**Switch1**

Law before	<input type="text" value="LawName1"/> <input type="button" value="▼"/>
Law after	<input type="text" value="LawName2"/> <input type="button" value="▼"/>
Type of Event	<input type="text" value="ECLIPSE"/> <input type="button" value="▼"/>
<input checked="" type="checkbox"/> Display event config	
Eclipse Detector	
Event type:	<input checked="" type="radio"/> Entering eclipse <input type="radio"/> Exiting eclipse <input type="radio"/> Entering/Exiting eclipse
Start at occurrence:	<input type="text" value="1"/>
Action:	<input type="text" value="RESET_STATE"/> <input type="button" value="▼"/>
<input type="checkbox"/> Display expert config	

## How to use it

To get a [[PATRIUS](#)] `AttitudeSequence` object, we will just have to call for the `getPatriusObject()` method as below:

```
AttitudesSequence seq = attSeq.getPatriusObject();
```

## How it is stored

Here is the [XML](#) format for a sequence:

```
<String name="dateMode">external</String>
<AbsoluteDate name="referenceDate">
  <String name="date">01/01/2000 00h00m00s</String>
  <String name="scale">UTC</String>
</AbsoluteDate>
<AbsoluteDate name="externalDate">
  <String name="date">01/01/2010 00h00m00s</String>
  <String name="scale">UTC</String>
</AbsoluteDate>
<AttitudeLawList name="lawList">
  <ComponentList name="AttitudeLaw">
    <!--Amount of items-->
    <Integer name="nbItems">2</Integer>
    <ComponentListItem name="Item_1">
      <String name="lawName">LawName1</String>
      <String name="lawType">LOF</String>
      <LOFAttitudeLaw name="LOF_Att._Law:>
        <String name="lawEvol">Constant</String>
        <String name="LOF">LVLH</String>
        <Frame name="Inertial">
          <String name="name">GCRF</String>
        </Frame>
        <Boolean name="biasAngles">true</Boolean>
        <Rotation name="Rotation:>
          <String name="rotationOrder">ZYX Cardan angles</String>
          <Real name="psi" unit="deg">1.8E2</Real>
          <Real name="theta" unit="deg">0.0E0</Real>
          <Real name="phi" unit="deg">0.0E0</Real>
        </Rotation>
      </LOFAttitudeLaw>
    </ComponentListItem>
    <ComponentListItem name="Item_2">
      <String name="lawName">LawName2</String>
      <String name="lawType">Inertial</String>
      <InertialAttitudeLaw name="Inertial_Att._Law:>
        <String name="lawEvol">Constant</String>
        <Frame name="referenceFrame">
          <String name="name">EME2000</String>
```

```

        </Frame>
        <Boolean name="biasAngles">false</Boolean>
    </InertialAttitudeLaw>
    </ComponentListItem>
</ComponentList>
</AttitudeLawList>
<SwitchingConditionList name="switchList">
    <ComponentList name="AttitudeSequenceSwitch">
        <!--Amount of items-->
        <Integer name="nbItems">1</Integer>
        <ComponentListItem name="Item_1">
            <String name="Law_before">LawName1</String>
            <String name="Law_after">LawName2</String>
            <EventSelector name="event">
                <String name="eventType">RELATIVE_DATE</String>
                <RelativeDateDetector name="EventData">
                    <DateOffset name="relativeDate">0j00h02m00s</DateOffset>
                    <String name="actionData">RESET_STATE</String>
                    <Real name="maxCheck" unit="s">1.0E10</Real>
                    <Real name="threshold" unit="s">1.0E-9</Real>
                </RelativeDateDetector>
            </EventSelector>
        </ComponentListItem>
    </ComponentList>
</SwitchingConditionList>

```

Récupérée de « <http://genopus.cnes.fr/index.php?title=GPAttitudeSequence&oldid=198> »

## Menu de navigation

### Outils personnels

- [3.143.168.172](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

### Espaces de noms

- [Page](#)
- [Discussion](#)

### Variantes

### Affichages

- [Lire](#)
- [Voir le texte source](#)

- [Historique](#)
- [Exporter en PDF](#)

## Plus

### Rechercher

  

## GENOPUS

- [Welcome](#)
- [Quick Start](#)
- [News](#)

## User Manual

- [BasicPrinciples](#)
- [GPAbsoluteDate](#)
- [GPOrbit](#)
- [GPFramesConfiguration](#)
- [GPVehicle](#)
- [GPForceModels](#)
- [GPManeuverSequence](#)
- [GPAltitudeSequence](#)
- [GPIntegrator](#)
- [GPAxisCoordinates](#)
- [GPGeodeticPoint](#)
- [GPOneAxisEllipsoid](#)
- [GPRotation](#)
- [GPConstants](#)
- [Events](#)
- [GPCorrelation](#)

## Evolutions

- [Main differences between V2.4.1 and V2.4.2](#)
- [Main differences between V2.3.3 and V2.4.1](#)
- [Main differences between V2.2.1 and V2.3.3](#)
- [Main differences between V2.2 and V2.2.1](#)
- [Main differences between V2.1.1 and V2.2](#)
- [Main differences between V2.1 and V2.1.1](#)
- [Main differences between V2.0.1 and V2.1](#)
- [Main differences between V2.0 and V2.0.1](#)

- [Main differences between V1.3.1 and V2.0](#)
- [Main differences between V1.3 and V1.3.1](#)
- [Main differences between V1.2.1 and V1.3](#)

## Training

- [Make your own propagator tool!](#)
- [Tutorials package for V2.4.1](#)
- [Tutorials package for V2.3.3](#)
- [Tutorials package for V2.2](#)
- [Tutorials package for V2.1.1](#)
- [Tutorials package for V2.0 and V2.0.1](#)
- [Tutorials package for V1.3 and V1.3.1](#)
- [Training slides](#)

## Links

- [CNES freeware server](#)

## Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)

• Dernière modification de cette page le 25 octobre 2017 à 15:59.

- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)

